















HOW TO USE FIBCS

The following handling instructions must be observed when operating with flexible intermediate bulk containers (FIBCs):

<p>1 Do read the instruction label on the FIBC</p> <p>2 Do keep within the safe working load (SWL)</p> <p>3 Do inspect reusable FIBCs for damage before refilling</p> <p>4 Do check that the discharge spout is closed off before filling</p> <p>5 Do ensure that the filled FIBC is stable</p> <p>6 Do close the top inlet correctly</p> <p>7 Do use lifting gear of sufficient capacity for the load</p> <p>8 Do adjust the distance between fork lift arms to the correct width for the FIBC being handled</p> <p>9 Do tilt the mast of the fork lift truck rearwards to an appropriate angle</p> <p>10 Do ensure that the area beneath the FIBC is clear of personnel</p> <p>11 Do ensure that crane hooks, bars or forklift arms used for lifting are of adequate size and are rounded off</p> <p>12 Do consider the possibility of static electricity hazards</p> <p>13 Do ensure stability when stacking FIBCs</p> <p>14 Do protect the FIBCs from rain and / or prolonged sunlight</p>	<p>2</p> 	<p>15 Do ensure that the FIBCs are adequately secured during transport</p> <p>16 Do not exceed the safe working load (SWL) under any circumstances</p> <p>17 Do not fill the FIBCs unevenly</p> <p>18 Do not accelerate or brake sharply during transport</p> <p>19 Do not subject FIBCs to snatchlift and / or jerk stops</p> <p>20 Do not drag FIBCs over the floor</p> <p>21 Do not use lifting equipment which has not been adjusted correctly for the FIBC</p> <p>22 Do not allow personnel under suspended FIBCs</p> <p>23 Do not tilt the mast of the forklift forward</p> <p>24 Do not withdraw the fork of the forklift until all the load is relieved</p> <p>25 Do not allow the use of unsuitable lifting devices</p> <p>26 Do not stack FIBCs unless sure of stability</p> <p>27 Do not use FIBCs in new conditions without consulting the manufacturer or supplier</p> <p>28 Do not reuse single-trip FIBCs</p> <p>29 Do not allow the repair and reuse of damaged reusable FIBCs without consulting the manufacturer or supplier</p>	<p>6</p> 
	<p>8</p> 		<p>21</p> 
	<p>8</p> 		<p>21</p> 
	<p>9</p>  <p>10</p> 		<p>22</p>  <p>23</p> 
	<p>11</p> 		<p>25</p> 
	<p>13</p>  <p>14</p> 		<p>26</p> 